



CARBON FIBER SCUTTLE – NM.958856

[R55] MINI Cooper Clubman All 2008-12

[R56] MINI Cooper Hardtop All 2007-12

[R57] MINI Cooper Convertible All 2009-12

PARTS INCLUDED:

- [1] Left Side Carbon Scuttle
- [2] Right Side Carbon Scuttle

TOOLS REQUIRED:

- [1] Cleaning Solvent or Degreaser
- [1] Soft Towel



1. Push Scuttle forward toward front of vehicle then pull out.



2. Rotate bulb housing counter clockwise 90°, and then pull out.

3. Clean fender with cleaner where Scuttle will be positioned.



4. Pull out bulb from Socket.



5. Turn on hazard blinkers then connect plugs to check if functioning. If not blinking reverse plug 180°.



6. Peel off tape backing and lightly apply to vehicle for correct positioning. Once aligned press firmly to all four corners.

©2011 NM Engineering, a division of Automotive Performance Systems, Inc.
All rights reserved. Reproduction in whole or in part is prohibited.
DOC. NM.668856 Rev. 11.09.11