

NEUSPEED®

REAR ANTI-ROLL BAR CLAMP AND BUSHING KIT FITS: AUDI A3/S3(8P) & AUDI TT(8J) FWD & QUATTRO ALL VW MK V, MK VI, CC, PASSAT & TIGUAN FWD & 4-MOTION VEHICLES EQUIPPED WITH NEUSPEED ANTI-ROLL BAR

PART # HCB.25.02.25.3 / HCB.25.02.28.3
INSTALLATION INSTRUCTIONS

PARTS LIST: 2 - BILLET CLAMPS W/ GREASE FITTINGS 1 - SILICONE GREASE
2 - URETHANE BUSHINGS 4 - M8X30MM SOCKET BOLT

TOOLS REQUIRED: 1 - RATCHET WRENCH
1 - M10 TRIPLE SQUARE (12 POINT) OR 8mm HEX KEY WRENCH
1 - 6mm HEX KEY WRENCH

1. Park car on a flat, level surface capable of supporting the vehicle's weight on jack and jack stands. Using the manufacturer's recommended lifting point(s), raise rear of vehicle and support with jack stands. **NEVER WORK ON A VEHICLE SUPPORTED ONLY WITH A JACK!**



2. Remove the bushing clamp mounting bolts using a M10 Triple Square or 8mm hex key wrench and remove original clamps and NEUSPEED bushings. **Note:** AWD models need to compress suspension for easier access to upper clamp bolt.

3. Clean old grease from NEUSPEED Anti-Roll Bar using WD-40 or equivalent.



4. Apply silicone grease to the inside of supplied bushings and install on the inside of stop washer on NEUSPEED Anti-Roll Bar.



5. Install NEUSPEED Anti-Roll Bar Billet Clamps with fittings facing downward and bolts supplied to sub-frame. Torque bolts to 24Nm (18 ft-lbs).

6. Double check complete installation.

7. Grease bushings yearly with grease gun.

Copyright 2012, NEUSPEED®. All rights reserved. Reproduction in whole or in part prohibited.
DOC.HCB.25.02.25.3 Rev. 08.23.12