

NEUSPEED®

2.0L SUPERCHARGER HP PULLEY

ANY VEHICLE EQUIPPED WITH NEUSPEED'S 2.0L SUPERCHARGER KIT

PART # 58.45.06.028

INSTALLATION INSTRUCTIONS

PART LIST:	1 – 2.6" PULLEY	1 – 18mm NUT
TOOLS REQ:	1 – RATCHET 1 – 18mm SOCKET	1 – PULLER SET 1 – STRAP WRENCH

1. Release tension from belt and remove ribbed V-belt from supercharger pulley.



2. Place strap wrench around pulley and remove M12 Nut (18mm Hex) securing pulley to supercharger shaft.



3. Slide pulley off of shaft. If you are unable to remove the pulley by hand, use a puller set. Do not use a hammer or pry bar to remove the pulley, since this will damage the pulley and/or shaft and void your supercharger's warranty.

4. Align keyway of new pulley with key on shaft and slide pulley into position. Install belt and tension to 25 ft-lbs.

5. Apply loc-tite (262 or 272) to threads and install nut. Torque nut to 45 ft-lbs.